




# SERVICE

*DUCKHART*

# 928 S4

## DIAGNOSIS OF THE INSTRUMENT CLUSTER




# '89

# INFORMATION

# TECHNIK

ON BOARD DIAGNOSIS



DIAGNOSIS  
OF THE INSTRUMENT CLUSTER

CONTENT	CHAPTER	PAGE
General		3
Operating-lever functions		4
Activating diagnosis		5
Instrument cluster diagnosis, reading fault memory	K	6
Fault warning display	K1.1	7
Clearing the fault memory, driving actuators	K1.2/K2	8
Checking sensors	K3	9
Checking switches	K4	12
Specific functions	K5	14

E = CRK memory


O N B O A R D D I A G N O S I S

The correct functioning of the INSTRUMENT CLUSTER itself, as well as diverse switches and sensors in the vehicle can be checked by means of the ON BOARD DIAGNOSIS. During diagnosis of the instrument cluster, the instrument's three display boxes are used to indicate:

- a.) the individual steps in the diagnosis,
- b.) the software status,
- c.) the duration and/or journey during which warnings were issued,
- d.) the ACTUAL values of sensors and switches.

The current diagnosis step is indicated in the left and right display boxes and the central display box indicates the control unit code.


e.g. display:




The control unit code contains a letter (K = instrument cluster) which is assigned an identification figure when diagnosis is activated, indicating the respective software status (e.g. K18) of the control unit.

The corresponding data values for each diagnosis step are indicated in the right-hand display box as either a code number or in plain text. Switches, sensors or actuators are also assigned a code number in the left-hand display box which identifies the respective component.


e.g. display:



Example :



OR :



**OPERATING LEVER functions**

The operating lever - to the left of the steering column - can be used to start the diagnosis as well as to select and activate the individual steps.


The operating lever can operate in 4 planes.

- to the **FRONT** = **start DIAGNOSIS**
- to the **REAR** = **execution desired - YES**
- **UPWARDS** = **execution desired - NO**
- **DOWNWARDS** = **execution desired - YES (clear memory only)**

**RULE**

If a question appears on the display during diagnosis, such as

e.g.




this question must be answered with **YES** or **NO** by moving the operating lever in order to continue in the diagnosis program.

**NOTE: Operating lever UPWARDS = NO - Do not execute display.  
Jump to next diagnosis step**

**Operating lever to the REAR = YES - Execute the display.**

**Exception:** There is one exception to this rule:

Display :



If you wish to clear the error memory (**YES**), the operating lever must be pressed **DOWNWARDS** - for approx. 1 s.

If the answer is **NO** move the operating lever **UPWARDS**.

**The contact bridge 9293 is required to start diagnosis.**  
The contact bridge 9293 must be plugged into the diagnosis-plug connector in the vehicle for this.

**NOTE:**

All other code letters shown in the central display box cannot be called at this time, or checked with the **PORSCHE System Tester 9268** (Off Board Diagnosis).

**1.) ACTIVATING DIAGNOSIS**

DISPLAY (example)

1a.) Turn on ignition	:	3510 KM	+22.0 * °C	185.5 KM I
1b.) Connect contact bridge 9293	:	3510 KM	+22.0 * °C	185.5 KM I
1c.) Move operating lever to the FRONT for approx. 3 s	:	OUTSIDE	+22.0 * °C	TEMPERATURE
followed by	:	PORSCHE		DIAGNOSIS

**2.) CALLING THE CLUSTER CONTROL UNIT**

Press the operating lever repeatedly UPWARDS or DOWNWARDS until the identification code **K** appears.

PORSCHE	K	DIAGNOSIS
---------	---	-----------

If a non-assigned code letter is called, e.g. 'A' - operating lever to the REAR, the following display appears:

-----	A	-----
-------	---	-------

After a short waiting period the display changes :

PORSCHE		DIAGNOSIS
---------	--	-----------

K.) INSTRUMENT CLUSTER DIAGNOSIS


At the beginning of model year '89, the software status code K18 was fitted for the instrument cluster. The software was modified during this model year. The subsequent new software status has been assigned the code K21.

**NOTE:** In order to read out all diagnosis steps without maloperation and with the correct values, we recommend that the instrument cluster diagnosis be carried out with the engine running (at idle).



START THE ENGINE

Operating lever to the REAR




K1.) READING THE FAULT MEMORY


**NOTE:**

The instrument cluster software status K18 contains a fault data memory, the content of which is of no significance to the Service. Once the last, existing fault has been read out, the display indicates any existing FAULT WARNING (diagnosis step K1.1), or jumps to the next diagnosis step K2.

The instrument cluster software status K21 has no fault data memory. Any existing FAULT WARNINGS (diagnosis step K1.1) are indicated, otherwise the system jumps to the next diagnosis step K2.



If NO, operating lever UPWARDS - Jump to the next diagnosis step K1.2.



.....  
To continue: operating lever to the REAR.

K1.1) Fault warning display

If a warning is given in the display while driving, the duration and/or the journey is stored with this fault and issued on the display during diagnosis.

The following warnings are stored:

- OIL PRESSURE : in h/min
- OIL LEVEL : in km
- BRAKE FLUID LEVEL : in h/min
- ENGINE TEMPERATURE : in h/min
- COOLANT LEVEL : in km
- TOOTHED BELT TENSION : in h/min

Example:

Display : OIL PRESSURE Kxx \_\_ 01:12\_H \_\_

Operating lever to the REAR

Display : COOLANT LEV. Kxx \_\_ 127.3\_KM \_\_

etc.

.....  
 Fault warning display TERMINATED - To continue: operating lever to the REAR.

**Note:** The fault warning display is cleared if the battery cable is disconnected or if the plug connections of the instrument cluster have been separated.

*12L OR 3gAL FOR RES. CALIBRATION*

K1.2.) CLEARING THE FAULT MEMORY

Display : 

MEMORY
--------

Kxx
-----

CLEAR?
--------

If NO, operating lever UPWARDS - Jump to the next diagnosis step K2.

If 'YES'  
operating lever DOWNWARDS  
for approx. 1 s : 

MEMORY
--------

Kxx
-----

CLEARED
---------

.....  
To continue: operating lever to the REAR.

K2.) DRIVING INSTRUMENT-CLUSTER ACTUATORS

Display : 

ACTUATORS
-----------

Kxx
-----

DRIVE?
--------

If NO, operating lever UPWARDS, jump to the next diagnosis step K3.

Operating lever to the REAR: 

ACTUATOR 01
-------------

Kxx
-----

DRIVEN
--------

  
TANK DISPLAY.  
The tank display must  
indicate 40  $\bar{L}$  = 1/2 TANK

Operating lever to the REAR: 

ACTUATOR 02
-------------

Kxx
-----

DRIVEN
--------

  
TANK DISPLAY:  
The tank display must  
indicate 80  $\bar{L}$  FULL TANK

Operating lever to the REAR: 

ACTUATOR 03
-------------

--

DRIVEN
--------

  
The checkered DISPLAY  
changes inversely.

Operating lever to the REAR: 

ACTUATOR 04
-------------

--

DRIVEN
--------

  
Only for vehicles with  
M 215 (Saudi Arabia): speed  
warning buzzer sounds.

.....  
Drive actuators TERMINATED - To continue: operating lever to the REAR



Attention: code number without ( ) = software status K18 + K21  
 code number in ( ) = software status K21 only

K3.) SENSORS

SENSORS	K18 (K21)	CHECK?
---------	--------------	--------

If NO - operating lever UPWARDS, jump to the next diagnosis step K3.1

Operating lever to the REAR:

SENSOR 01	K18 (K21)	xxx
-----------	--------------	-----

Each movement of the operating lever to the REAR - jump to the next sensor.

SENSOR	CODE	COMPONENT	NOMINAL VALUES
--------	------	-----------	----------------

01 PHOTOTRANSISTOR

00 - 255

If the phototransistor is covered with your hand and/or the sidelight terminal 58d is switched on, the displayed value (code) must be smaller. The displayed value must be higher if the phototransistor is illuminated externally.

02 INSTRUMENT LIGHTING, Terminal 58d

Voltage on Terminal 58d

00 = switched off  
 34 - 255 = switched on

*EXAMPLE*  
 143  
 10 = 12.2

Code No. = Voltage  
 16

When the instrument-potentiometer is adjusted, the indicated value (code) must be reduced or increased accordingly.

03 OUTSIDE TEMPERATURE (°C) (Sensor value(Ω))

25	60°	750
34	50°	1 K
48	40°	1.6 K
66	30°	2.5 K
90	20°	3.8 K
120	10°	6 K
136	5°	7.6 K
150	0°	9.8 K
169	- 5°	12.6 K
185	- 10°	16.5 K
213	- 20°	29 K
234	- 30°	53 K
248	- 40°	100 K

*ERROR 01 DEAD BATTERY*



**K3.) SENSORS**

SENSOR <b>xx</b>	K18 (K21)	<b>xxx</b>
------------------	--------------	------------

SENSOR    CODE	COMPONENTS	NOMINAL VALUES
08	OIL PRESSURE SENSOR (bar)	(Sensor value(Ω))
INDICATION :		
	on the instrument    *	on the display
29	0.0 *	0.0            10
70	1.0 *	0.6            29.6
97	1.5 *	1.0            48
116	2.0 *	1.6            65.3
131	2.5 *	2.0            82
143	3.0 *	2.4 (2.6)      99
153	3.5 *	2.8 (3.0)      116
162	4.0 *	3.2 (3.7)      133.6
169	4.5 *	3.7 (4.2)      151
180	5.0 *	4.5 (5.0)      184

The reasons for different indications on instrument and display are due to the tolerances of the analog instrument.

09	ALTERNATOR, Terminal 61	
96		6 V
112		7 V
128		.
144		.
160	Code No.	= Voltage
176	16	.
192		.
208		.
224		.
240		15 V
255		16 V

.....  
TO CONTINUE - operating lever to the REAR.

**K3.1) INPUT VARIABLES**

Specific dynamic input variables of the instrument cluster may be shown with the correct unit. The display follows automatically after diagnosis step K3 'SENSORS CHECK?'.

Operating lever to the REAR: 

OIL PRESSURE
--------------

K18 (K21)
--------------

x.x BAR
---------

Operating lever to the REAR: 

ENG. SPEED
------------

K18 (K21)
--------------

xxxx RPM
----------

At the present time, only the OIL PRESSURE and ENGINE SPEED can be called up. Differing indications between the analog and digital display are OK as long as the analog display deviations are not greater than +0.7 bar or ± 1.5 % of the full-scale value at 400 - 2500 rpm.

.....  
Sensor diagnosis TERMINATED - To continue: operating lever to the REAR

**K4.) SWITCHES**

<b>SWITCH</b>	K18 (K21)	<b>CHECK?</b>
---------------	--------------	---------------

If NO - operating lever UPWARDS, jump to the next diagnosis step K5.


Operating lever to the REAR:

SWITCH 01	K18 (K21)	_____
-----------	--------------	-------

Each movement of the operating lever to the REAR - Jump to the next switch.

SWITCH	COMPONENTS	SWITCH	DISPLAY
01	PARK BRAKE	Not operated Operated (-)	OPEN CLOSED
02	No function		OPEN
03	ABS	System OK Not OK (-)	OPEN CLOSED
<del>04</del>	No function		OPEN
<del>05</del>	RDK	Not installed Installed (-)	OPEN CLOSED
06	CAT. MONITOR	System OK Not OK (-)	OPEN CLOSED
<del>07</del>	No function		OPEN
08	WASHER WATER LEV.	Level OK Not OK (-)	OPEN CLOSED
09	COOLANT LEVEL	Level OK Not OK (-)	OPEN CLOSED
10	COOLANT PRESSURE	OK ≤ 0.1 bar ≥ 0.1 bar (-)	OPEN CLOSED

K4.) SWITCHES




SWITCH	COMPONENTS	SWITCH	DISPLAY
11	OIL LEVEL	OK > 6 l Not OK <6 l	OPEN CLOSED
12	TOOTHED BELT TENS.	Tension OK Not OK (+)	OPEN CLOSED
13	BRAKE PADS	Pad OK Not OK (-)	OPEN CLOSED
14	BRAKE FLUID	Level OK Not OK (-)	OPEN CLOSED
15	BRAKE-LIGHT SWITCH	Not operated Operated (+)	OPEN CLOSED
16	BRAKE LIGHT	OK Not OK (-)	OPEN CLOSED
17	CENTRAL LOCKING	Not operated Operated (-)	OPEN CLOSED
<del>18</del>	No function		OPEN
<del>19</del>	No function		OPEN
20	<sup>Speed 0</sup> <del>TACHOMETER SIGNAL</del> Output	Rear wheels turn	OPEN CLOSED
<del>21</del>	No function		OPEN
22	OIL-PRESSURE SWITCH	OK > 2.5 bar Not OK (-) < 0.25 bar	OPEN CLOSED
23	SAFETY BELT	Not closed Closed	OPEN CLOSED
24	TAIL LAMP	OK Not OK (-)	OPEN CLOSED
25	<sup>Speed 0</sup> <del>TACHO RESET</del> <sup>green "0" button on console</sup>	Not operated Operated (-)	OPEN CLOSED

.....  
Switch diagnosis TERMINATED - To continue: operating lever to the REAR


**K5.) SPECIFIC FUNCTIONS**

The operating time of the vehicle can be interrogated with this program without a tachometer signal (driving without tachometer connected). *SPEEDO*


If 'NO', operating lever UPWARDS.



If 'YES', operating lever to the REAR for approx. 6 s.



Example:



*CODE 200 means disconnected*



Calculation from the display:


Failure time in minutes = (value 1 x 256) + value 2

Failure period in hours =  $\frac{(\text{value 1} \times 256) + \text{value 2}}{60}$

.....  
Specific functions TERMINATED

Instrument cluster diagnosis TERMINATED - Operating lever to the REAR


Display :



To continue diagnosis - operating lever to the REAR - repeat instrument cluster diagnosis.

Interrupt diagnosis - switch off ignition, remove contact bridge.

If you forget to move the contact bridge, the following display appears when the ignition is switched on again:



\*\*\*\*\*  
TERMINATED